





NOTE: All components on this page are located outside of the low mass section of the cable. The pads shown labeled as "fw\_pad" are used to attach the fine wire pairs that go to the MTB.